



INSTRUCTIONS

Windchaser Flags



Includes:
Aluminum Pole
Aluminum Banner Arm
with Stopper
Ground Spike



1

Take the two longer poles and slide together.



2

Put flag on long pole and attach top pole through upper pole sleeve. Tighten nut.



3

If using as an in-ground application, place assembly into spike after location is determined and spike has been installed.



This product is for outdoor promotional use only and should not be left out in extreme weather conditions.

Please use common sense guidelines and do not display this product outdoors when extreme winds or storms may be present.

